

Index

Part Number	Description	Category, Section-Page
5100-0001	Sensor, Dial-a-Ducer, Lithium Battery	Discontinued
6200-0005	Fitting, #8 Hose Clamp	1,A4
6200-0022	Fitting, Power Pipe High Torque Clamp	1,A5/7,A3
6240-0001	Fitting, Tank Valve (with Cap).	1,A6/7,A3
6240-0002	Fitting, 1/8" NPT-M to 3/8" Tubing	1,A2
6240-0003	Fitting, 1/4" NPT-M to 3/8" Tubing	1,A2/7,A3
6240-0008	Fitting, Street L, 1/4" NPT-M to 3/8" Tubing, Forged.	1,A2
6240-0009	Fitting, Barbed Connector, 3/4" NPT-M	1,A6
6240-0013	Fitting, 1/8"NPT-F to Twin Hose	1,A3
6240-0014	Fitting, 1/8" NPT-M to Twin Hose	1,A3
6240-0015	Fitting, Tank Valve (5/16"-32 F)to Twin Hose	1,A3
6240-0018	Fitting, Plug, 1/8" NPT-M Hex Head	1,A4/7,A3
6240-0019	Fitting, Hex Coupling, 1/8" NPT-F (Minimum order qty: 10)	1,A2
6240-0021	Fitting, Plug, 3/4" NPT-M Hex Head	1,A5/7,A3
6240-0022	Fitting, Street L, 1/8" NPT-M to 3/8" Tubing, Forged.	1,A5
6240-0023	Fitting, Coupling, 3/8" Tubing.	1,A2
6240-0026	Fitting, 1/4" NPT-M to 1/2" Tubing	1,A2
6240-0027	Fitting, Street L, 1/8" NPT-M to 1/8" NPT-F, Bar Stock.	1,A3
6240-0029	Fitting, Plug, 1/8" NPT-M Hex Head	1,A4
6240-0032	Fitting, Valve Cap with Tool	1,A6
6240-0039	Fitting, Street L, 1/4" NPT-M to 1/4" NPT-F, Bar Stock.	1,A2
6240-0042	Fitting, Bushing, 3/4" NPT-M to 1/4" NPT-F	1,A3/7,A3
6240-0043	Fitting, Plug, 1/4" NPT-M Hex Head	1,A4/7,A3
6240-0047	Fitting, Nipple, 1/4" NPT-M to 1/4" NPT-M	1,A4/7,A3
6240-0050	Fitting, Power Pipe Cross, 3/4" NPT-F (4 Places), Forged	1,A5/7,A3
6240-0057	Fitting, 45° Street L, 1/4" NPT-M to 1/4" NPT-F, Bar Stock.	1,A2
6240-0058	Fitting, Bushing, 1/4" NPT-M to 1/8" NPT-F	1,A3/7,A3
6240-0063	Fitting, Street L, 1/4" NPT-M to 1/4" NPT-F, Forged.	1,A3
6240-0065	Fitting, Extender Adapter, 1/8" NPT-M to 1/8" NPT-F, Brass	1,A6
6240-0119	Fitting, Hex Nipple, 3/4" NPT-M (Minimum order qty: 10)	1,A5
6240-0120	Fitting, Power Pipe, Street L, 3/4" NPT-M to 3/4" NPT-F, Bar Stock.	1,A5/7,A2
6240-0121	Fitting, Ball Valve, 3/4" NPT-F T-knob	6,B3
6240-0125	Fitting, Street T, 1/8" NPT-M to 1/8" NPT-F (2 Places), Bar Stock	1,A3
6240-0130	Fitting, Branch T, 1/8" NPT-M to 1/8" NPT-F (2 Places), Bar Stock.	1,A3
6240-0142	Fitting, Check Valve, 1/4" NPT-F (2 Places), Panel Use.	1,A4
6240-0143	Fitting, Bushing, 1/4" NPT-M to 1/8" NPT-F, Nylon	1,A3
6240-0144	Fitting, Power Pipe, Bonding Strap Clamp	1,A5/7,A3
6240-0145	Fitting, Check Valve, 3/8" NPT-F to 3/4" NPT F	1,A4/7,A4
6240-0156	Fitting, Street L, 1/4" NPT-M to 1/8" NPT-F, Forged.	1,A3
6240-0157	Fitting, Elbow, 3/4" NPT-F (2 Places).	1,A5/7,A3
6240-0158	Fitting, Bushing, 3/4" NPT-M to 3/8" NPT-F, Nylon	1,A3
6240-0163	Fitting, Nipple, 1/4" NPT-M to 1/4" NPT-M, 2.5" Long	1,A4
6240-0167	Fitting, Bushing, 3/8" NPT-M to 1/4" NPT-F	1,A3
6240-0176	Fitting, Bushing, 2" NPT-M to 3/4" NPT-F, 304 Stainless Steel.	1,A3
6240-0180	Fitting, Check Valve, 1/4" NPT-M to 1/4" NPT-F, Field Use	1,A4
6240-0181	Fitting, Check Valve, 1/4" NPT-F to 1/4" NPT-M, Field Use	1,A4
6240-0184	Fitting, Bushing, 1" NPT-M to 3/4" NPT-F.	1,A3
6240-0190	Fitting, 45° Street L, 3/4" NPT-M to 3/4" NPT-F	1,A5
6240-0191	Fitting, Union T, 3/4" NPT-F (3 Places), Bar Stock	1,A5
6510-0062	Panel, 289H-M Mounting Bracket.	10,C6
6510-0085	Pipe/Power Pipe, Four Port Manifold	7,A2
6510-0086	Pipe/Power Pipe, Two Port Manifold	7,A2
6510-0104	Panel, Equipment Rack, Wall Bracket	6,B2

6514-0053	LSS, Connector Block, Label, Dedicated	10,C5
6514-0054	LSS, Connector Block, Label, Subscriber	10,C5
6522-0012	Pipe/Power Pipe, 1" Air Pipe Cap Plug	7,A4
6522-0013	Pipe/Power Pipe, Spacer.	7,A4
6522-0029	Pipe/Power Pipe, 3/8" Poly Tubing	7,A9
6522-0046	Pipe/Power Pipe, 1" Air Pipe Tapered Cap Plug	7,A4
6522-0048	Tool, Power Pipe, Water Removal Plug.	7,A10
6522-0068	Sensor, Seal, Molded Wire Cover	8,E1
6538-0003	Panel, Miscellaneous, 9-Port C.O. Manifold	6,B2
6538-0005	Panel, Miscellaneous, 3-Port (Short) C.O. Manifold	6,B2
6538-0009	Panel, Miscellaneous, 18-Port C.O. Manifold	6,B2
6550-0004	Panel, Miscellaneous, 0-30 PSI Air Pressure Regulator	6,B3/11,A2
6990-0027	Panel, Rack Manifold, Mounting Bracket	6,B3
7900-0011	Pipe/Power Pipe, One-Inch Nyla-Braid Tubing.	7,A9
7900-0025	Pipe/Power Pipe, One-Inch Stainless Steel Reinforced Poly Tubing	7,A9
9010-0003	LSS, Backplane Panel	10,C5
9010-0004	LSS, Utility Card	10,C1
9010-0010	LSS, Controller Card	10,C1
9010-0016	LSS, Tone Utility Card	10,C1
9010-0060	LSS, uM260 Micro Monitor, Termination Adapter, 6-Pair.	10,A3
9010-0062	LSS, uM260 Micro Monitor, Termination Adapter, 21-Pair.	10,A3
9010-0110	LSS, Expansion Chassis	10,C5
9080-0055	Sensor, TD Housing Splice Assembly.	8,E1
9080-0085	Sensor, Pair Splitter "Y" Connector.	8,E1
9080-1404	Panel, Rack Manifold, Bell Housing Assembly	6,B3
9800-0030	LSS, LAN Controller Card	10,C2
9800-0140	Fitting, Power Pipe Straight Splice, Quadruple O-Ring per Side	1,A5/7,A2
9800-0141	Fitting, Power Pipe End Connector, 3/4" NPT-M to Quadruple O-Ring	1,A5/7,A2
9800-0142	Fitting, Splice Case Check Valve Assembly	1,A6/6,B3
9800-0260	LSS, Manual, uM260.	10/C5
9800-0550	Miscellaneous Products, Purge Valve Assembly, Replacement	11,A2
9800-0901	Miscellaneous Products, Emergency Air Feeder Assembly	11,A1
9800-0902	Miscellaneous Products, Emergency Air Receiver Assembly	11,A1
9800-0905	Miscellaneous Products, Emergency Air Delivery Access Cabinet.	11,A1
9800-0911	Miscellaneous Products, 0911 Emergency Air Dryer	11,A1
9800-1100	Miscellaneous Products, Theory & Practice Package for Training Class	11,A2
9800-1125	Miscellaneous Products, Cable Pressurization Theory & Practice Book	11,A2
9800-1450-28	Computer, Software, Manual, PressureMAP System Administration	5,A2
9800-1460-28	Computer, Software, Manual, PressureMAP Operation	5,A2
9800-1470-28	Computer, Software, Manual, PressureMAP Installation	5,A2
9800-1480-28	Computer, Software, Manual, PressureMAP Data Entry	5,A2
9800-1491	LSS, Manual, 289H	10,C5
9800-1492	LSS, Manual, 289H-M	10,C5
9800-1900	Miscellaneous Products, Solar Cell Calculator.	11,A2
9800-1901	Miscellaneous Products, Pocket Pressurization Calculator Card.	11,A3
9800-1902	Miscellaneous Products, Pocket Cable Identification Card	11,A3
9800-3001	Fitting, 1/2" Air Pipe 3 Way Tee.	1,A1/7,A8
9800-3003	Flow Finder, 0-9.5 SCFH, w/out Check Valve.	3,A2
9800-3005	Flow Finder, 0-19 SCFH, w/out Check Valve	3,A2
9800-3006	Flow Finder, 0-47.5, w/out Check Valve	3,A2
9800-3008	Flow Finder, 0-95, w/out Check Valve	3,A2
9800-3010	Flow Finder, Assembly, High Valve	3,A3
9800-3011	Flow Finder, Assembly, Pair Pipe.	3,A3
9800-3013	Fitting, 1/2" Pipe, Pulling Eye	Discontinued
9800-3015	Flow Finder, Calibrated Leak	3,A3
9800-3019	Fitting, AMP, Pipe End	Discontinued
9800-3023	Fitting, 1/4" NPT-M to 3/8" Tubing (Bag of 10)	1,A2
9800-3024	Fitting, Bypass Valve	1,A6



9800-3026	Flow Finder, Special Restrictor	3,A2
9800-3031	Flow Finder, Twin Tubing	3,A3/7,A9
9800-3031-C	Flow Finder, Twin Tubing, 2,000 Feet Reel.	3,A3/7,A9
9800-3035	Fitting, Flow Limiter, 1/4" NPT-M to 1/4" NPT-F	1,A4/7,A2
9800-3036	Fitting, Flow Limiter, 1/4" NPT-M to 1/4" NPT-M	1,A4/7,A2
9800-3037	Fitting, Reducer, 3/4" NPT-F to 1/4" NPT-F	1,A4/7,A2
9800-3039	Flow Finder, Jumper Strap	3,A3/7,A8
9800-3051	Fitting, AMP, Shutoff Valve	1,A1/7,A8
9800-3054	Fitting, CA3131 to Pipe Panel, with Ground Lug	1,A1/7,A8
9800-3055	Fitting, 1/2" Air Pipe End Cap Coupler with Tank Valve	1,A1/7,A8
9800-3057	Fitting, Air Pipe Coupler, with Ground Lug	1,A2/7,A8
9800-3060-HBS	Manifold, 6-Port, High Range, 3/8" Brass Fittings	4,A2
9800-3060-HBT	Manifold, 6-Port, High Range, 1/4" Brass Fittings	4,A3
9800-3060-HBV	Manifold, 6-Port, High Range, 3/8" Brass Fittings, Check Valves	4,A2
9800-3060-HSS	Manifold, 6-Port, High Range, 37° Flared Stainless Steel Fittings	4,A2
9800-3060-HSV	Manifold, 6-Port, High Range, 37° Flared Stainless Steel Fittings, Check Valves	4,A2
9800-3060-LBS	Manifold, 6-Port, Low Range, 3/8" Brass Fittings	4,A2
9800-3060-LBT	Manifold, 6-Port, Low Range, 1/4" Brass Fittings	4,A3
9800-3060-LBV	Manifold, 6-Port, Low Range, 3/8" Brass Fittings, Check Valves	4,A2
9800-3060-LSS	Manifold, 6-Port, Low Range, 37° Flared Stainless Steel Fittings	4,A2
9800-3060-LSV	Manifold, 6-Port, Low Range, 37° Flared Stainless Steel Fittings, Check Valves	4,A2
9800-3060-MBS	Manifold, 6-Port, Medium Range, 3/8" Brass Fittings	4,A2
9800-3060-MBT	Manifold, 6-Port, Medium Range, 1/4" Brass Fittings	4,A3
9800-3060-MBV	Manifold, 6-Port, Medium Range, 3/8" Brass Fittings, Check Valves	4,A2
9800-3060-MSS	Manifold, 6-Port, Medium Range, 37° Flared Stainless Steel Fittings	4,A2
9800-3060-MSV	Manifold, 6-Port, Medium Range, 37° Flared Stainless Steel Fittings, Check Valves	4,A2
9800-3061-HBS-1	Manifold, Assembly, Single, High Range, 3/8" Brass Fittings, Flow TD	4,B2
9800-3061-HBS-2	Manifold, Assembly, Single, High Range, 3/8" Brass Fittings, Dual TD	4,B2
9800-3061-HBT-1	Manifold, Assembly, Single, High Range, 1/4" Brass Fittings, Flow TD	4,B2
9800-3061-HBT-2	Manifold, Assembly, Single, High Range, 1/4" Brass Fittings, Dual TD	4,B2
9800-3061-HBV-1	Manifold, Assembly, Single, High Range, 3/8" Brass Fittings, Check Valves, Flow TD	4,B2
9800-3061-HBV-2	Manifold, Assembly, Single, High Range, 3/8" Brass Fittings, Check Valves, Dual TD	4,B2
9800-3061-LBS-1	Manifold, Assembly, Single, Low Range, 3/8" Brass Fittings, Flow TD	4,B1
9800-3061-LBS-2	Manifold, Assembly, Single, Low Range, 3/8" Brass Fittings, Dual TD	4,B1
9800-3061-LBS-9	Manifold, Assembly, Single, Low Range, 3/8" Brass Fittings, No TD	4,B5
9800-3061-LBS-U	Manifold, Assembly, Single, Low Range, 3/8" Brass Fittings, UE Resistive Flow TD	4,B6
9800-3061-LBS-U2	Manifold, Assembly, Single, Low Range, 3/8" Brass Fittings, UE Resistive Flow and Pressure TDs	4,B6
9800-3061-LBT-1	Manifold, Assembly, Single, Low Range, 1/4" Brass Fittings, Flow TD	4,B2
9800-3061-LBT-2	Manifold, Assembly, Single, Low Range, 1/4" Brass Fittings, Dual TD	4,B2
9800-3061-LBV-1	Manifold, Assembly, Single, Low Range, 3/8" Brass Fittings, Check Valves, Flow TD	4,B2
9800-3061-LBV-2	Manifold, Assembly, Single, Low Range, 3/8" Brass Fittings, Check Valves, Dual TD	4,B2
9800-3061-LBV-U	Manifold, Assembly, Single, Low Range, 3/8" Brass Fittings, Check Valves, UE Resistive Flow TD	4,B6
9800-3061-MBS-1	Manifold, Assembly, Single, Medium Range, 3/8" Brass Fittings, Flow TD	4,B2
9800-3061-MBS-2	Manifold, Assembly, Single, Medium Range, 3/8" Brass Fittings, Dual TD	4,B2
9800-3061-MBT-1	Manifold, Assembly, Single, Medium Range, 1/4" Brass Fittings, Flow TD	4,B2
9800-3061-MBT-2	Manifold, Assembly, Single, Medium Range, 1/4" Brass Fittings, Dual TD	4,B2
9800-3061-MBV-1	Manifold, Assembly, Single, Medium Range, 3/8" Brass Fittings, Check Valves, Flow TD	4,B2
9800-3061-MBV-2	Manifold, Assembly, Single, Medium Range, 3/8" Brass Fittings, Check Valves, Dual TD	4,B2
9800-3062-HBS-1	Manifold, Assembly, Dual, High Range, 3/8" Brass Fittings, Flow TD	4,B4
9800-3062-HBS-2	Manifold, Assembly, Dual, High Range, 3/8" Brass Fittings, Dual TD	4,B4
9800-3062-HBV-1	Manifold, Assembly, Dual, High Range, 3/8" Brass Fittings, Check Valves, Flow TD	4,B4
9800-3062-HBV-2	Manifold, Assembly, Dual, High Range, 3/8" Brass Fittings, Check Valves, Dual TD	4,B4
9800-3062-LBS-1	Manifold, Assembly, Dual, Low Range, 3/8" Brass Fittings, Flow TD	4,B4
9800-3062-LBS-2	Manifold, Assembly, Dual, Low Range, 3/8" Brass Fittings, Dual TD	4,B4
9800-3062-LBS-9	Manifold, Assembly, Dual, Low Range, 3/8" Brass Fittings, No TD	4,B6
9800-3062-LBS-U	Manifold, Assembly, Dual, Low Range, 3/8" Brass Fittings, UE Resistive Flow TD	4,B6

9800-3062-LBV-1	Manifold, Assembly, Dual, Low Range, 3/8" Brass Fittings, Check Valves, Flow TD	4,B4
9800-3062-LBV-2	Manifold, Assembly, Dual, Low Range, 3/8" Brass Fittings, Check Valves, Dual TD	4,B4
9800-3062-LBV-U	Manifold, Assembly, Dual, Low Range, 3/8" Brass Fittings, Check Valves, UE Resistive Flow TD	4,B6
9800-3062-MBS-1	Manifold, Assembly, Dual, Medium Range, 3/8" Brass Fittings, Flow TD	4,B4
9800-3062-MBS-2	Manifold, Assembly, Dual, Medium Range, 3/8" Brass Fittings, Dual TD	4,B4
9800-3062-MBS-U	Manifold, Assembly, Dual, Medium Range, 3/8" Brass Fittings, Resistive Flow Transducer	4,B6
9800-3062-MBS-U2	Manifold, Assembly, Dual, Medium Range, 3/8" Brass Fittings, Resistive Flow and Pressure Transducers	4,B6
9800-3062-MBV-1	Manifold, Assembly, Dual, Medium Range, 3/8" Brass Fittings, Check Valves, Flow TD	4,B4
9800-3062-MBV-2	Manifold, Assembly, Dual, Medium Range, 3/8" Brass Fittings, Check Valves, Dual TD	4,B4
9800-3063-W-NN-1	Flow Finder, Assembly, 0-9.5 SCFH, No Fittings, Flow TD	3,B2
9800-3063-W-NN-2	Flow Finder, Assembly, 0-9.5 SCFH, No Fittings, Dual TD	3,B2
9800-3063-XBS-1	Flow Finder, Assembly, 0-19 SCFH, 3/8" Brass Fittings, Flow TD	3,B2
9800-3063-XBS-2	Flow Finder, Assembly, 0-19 SCFH, 3/8" Brass Fittings, Dual TD	3,B2
9800-3063-X-NN-1	Flow Finder, Assembly, 0-19 SCFH, No Fittings, Flow TD	3,B2
9800-3063-X-NN-2	Flow Finder, Assembly, 0-19 SCFH, No Fittings, Dual TD	3,B2
9800-3063-XX-NN-1	Flow Finder, Assembly, 0-190 SCFH, No Pipe Fittings, Flow TD	3,B2
9800-3063-XX-NN-2	Flow Finder, Assembly, 0-190 SCFH, No Pipe Fittings, Dual TD	3,B2
9800-3063-XX-PP-1	Flow Finder, Assembly, 0-475 SCFH, 1" Pipe Fittings, Flow TD	3,B2
9800-3063-XX-PP-2	Flow Finder, Assembly, 0-475 SCFH, 1" Pipe Fittings, Dual TD	3,B2
9800-3063-YBS-1	Flow Finder, Assembly, 0-47.5 SCFH, 3/8" Brass Fitting, Flow TD	3,B2
9800-3063-YBS-2	Flow Finder, Assembly, 0-47.5 SCFH, 3/8" Brass Fitting, Dual TD	3,B2
9800-3063-Y-NN-1	Flow Finder, Assembly, 0-47.5 SCFH, No Fittings, Flow TD	3,B2
9800-3063-Y-NN-2	Flow Finder, Assembly, 0-47.5 SCFH, No Fittings, Dual TD	3,B2
9800-3063-YY-NN-1	Flow Finder, Assembly, 0-475 SCFH, No Pipe Fittings, Flow TD	3,B3/7A2
9800-3063-YY-NN-2	Flow Finder, Assembly, 0-475 SCFH, No Pipe Fittings, Dual TD	3,B3/7A2
9800-3063-YY-PP-1	Flow Finder, Assembly, 0-475 SCFH, 1" Pipe Fittings, Flow TD	3,B3/7A2
9800-3063-YY-PP-2	Flow Finder, Assembly, 0-475 SCFH, 1" Pipe Fittings, Dual TD	3,B3/7A2
9800-3063-YY-PP-3	Flow Finder, Assembly, 0-475 SCFH, One Inch Pipe Fittings, Dual Bi-Directional TD	3,B3
9800-3063-Z-NN-1	Flow Finder, Assembly, 0-95 SCFH, No Fittings, Flow TD	3,B2
9800-3063-Z-NN-2	Flow Finder, Assembly, 0-95 SCFH, No Fittings, Dual TD	3,B2
9800-3064-CSV-2	Manifold, Assembly, Single, Custom Range, 37° Stainless Steel Fittings, Dual Transducer	4,B3
9800-3064-CSV-2P	Manifold, Assembly, Single, Custom Range, 37° Stainless Steel Fittings, Check Valves, Dual Transducer w/ Pair Saver	4,B5
9800-3064-HSS-1	Manifold, Assembly, Single, High Range, 37° Stainless Steel Fittings, Flow TD	4,B3
9800-3064-HSS-2	Manifold, Assembly, Single, High Range, 37° Stainless Steel Fittings, Dual TD	4,B3
9800-3064-HSV-1	Manifold, Assembly, Single, High Range, 37° Stainless Steel Fittings, Check Valves	4,B3
9800-3064-HSV-2	Manifold, Assembly, Single, High Range, 37° Stainless Steel Fittings, Check Valves	4,B3
9800-3064-HSV-2P	Manifold, Assembly, Single, High Range, 37° Stainless Steel Fittings, Check Valves, Dual Transducer w/Selector Pair Saver	4,B5
9800-3064-LSS-1	Manifold, Assembly, Single, Low Range, 37° Stainless Steel Fittings, Flow TD	4,B3
9800-3064-LSS-2	Manifold, Assembly, Single, Low Range, 37° Stainless Steel Fittings, Dual TD	4,B3
9800-3064-LSV-1	Manifold, Assembly, Single, Low Range, 37° Stainless Steel Fittings, Check Valves	4,B3
9800-3064-LSV-2	Manifold, Assembly, Single, Low Range, 37° Stainless Steel Fittings, Check Valves	4,B3
9800-3064-LSV-2P	Manifold, Assembly, Single, Low Range, 37° Stainless Steel Fittings, Check Valves, Dual Transducer w/Selector Pair Saver	4,B4
9800-3064-MSS-1	Manifold, Assembly, Single, Medium Range, 37° Stainless Steel Fittings, Flow TD	4,B3
9800-3064-MSS-2	Manifold, Assembly, Single, Medium Range, 37° Stainless Steel Fittings, Dual TD	4,B3
9800-3064-MSV-1	Manifold, Assembly, Single, Medium Range, 37° Stainless Steel Fittings, Check Valves	4,B3
9800-3064-MSV-2	Manifold, Assembly, Single, Medium Range, 37° Stainless Steel Fittings, Check Valves	4,B
9800-3065-HSV-2	Manifold, Assembly, Dual, High Range, 37° Stainless Steel Fittings, Check Valve, Dual Transducer	4,B4
9800-3065-HSV-2P	Manifold, Assembly, Dual, High Range, 37° Stainless Steel Fittings, Check Valves, Dual Transducer with Pair Saver	4,B5
9800-3065-MBV-1	Manifold, Assembly, Dual, Medium Range, 3/8" Brass Fittings, Check Valves	4,B4
9800-3065-MBV-2	Manifold, Assembly, Dual, Medium Range, 3/8" Brass Fittings, Check Valves	4,B4

9800-3066-W-NN-1	Flow Finder, Assembly, 0-9.5 SCFH, No Fittings, Flow TD	3,B2
9800-3066-W-NN-2	Flow Finder, Assembly, 0-9.5 SCFH, No Fittings, Dual TD	3,B2
9800-3066-X-NN-1	Flow Finder, Assembly, 0-19 SCFH, No Fittings, Flow TD	3,B2
9800-3066-X-NN-2	Flow Finder, Assembly, 0-19 SCFH, No Fittings, Dual TD	3,B2
9800-3066-XX-NN-1	Flow Finder, Assembly, 0-190 SCFH, No Pipe Fittings, Flow TD	3,B3
9800-3066-XX-NN-2	Flow Finder, Assembly, 0-190 SCFH, No Pipe Fittings, Dual TD	3,B3
9800-3066-XX-PP-1	Flow Finder, Assembly, 0-475 SCFH, 1" Pipe Fittings, Flow TD	3,B3
9800-3066-XX-PP-2	Flow Finder, Assembly, 0-475 SCFH, 1" Pipe Fittings, Dual TD	3,B3
9800-3066-Y-NN-1	Flow Finder, Assembly, 0-47.5 SCFH, No Fittings, Flow TD	3,B2
9800-3066-Y-NN-2	Flow Finder, Assembly, 0-47.5 SCFH, No Fittings, Dual TD	3,B2
9800-3066-YY-NN-1	Flow Finder, Assembly, 0-475 SCFH, 1" Pipe Fittings, Flow TD	3,B3/7A2
9800-3066-YY-NN-2	Flow Finder, Assembly, 0-475 SCFH, 1" Pipe Fittings, Dual TD	3,B3/7A2
9800-3066-YY-PP-1	Flow Finder, Assembly, 0-475 SCFH, 1" Pipe Fittings, Flow TD	3,B3/7A1
9800-3066-YY-PP-2	Flow Finder, Assembly, 0-475 SCFH, 1" Pipe Fittings, Dual TD	3,B3/7A1
9800-3066-Z-NN-1	Flow Finder, Assembly, 0-95 SCFH, No Fittings, Flow TD	3,B2
9800-3066-Z-NN-2	Flow Finder, Assembly, 0-95 SCFH, No Fittings, Dual TD	3,B2
9800-3070-CSV	Manifold, 5-Port, Custom, 37° Flared Stainless Steel Fittings, Check Valve	4,A3
9800-3070-HBS	Manifold, 5-Port, High Range, 3/8" Brass Fittings	4,A3
9800-3070-HBT	Manifold, 5-Port, High Range, 1/4" Brass Fittings	4,A4
9800-3070-HBV	Manifold, 5-Port, High Range, 3/8" Brass Fittings, Check Valves	4,A3
9800-3070-HSS	Manifold, 5-Port, High Range, 37° Flared Stainless Steel Fittings	4,A3
9800-3070-HSV	Manifold, 5-Port, High Range, 37° Flared Stainless Steel Fittings, Check Valves	4,A3
9800-3070-LBS	Manifold, 5-Port, Low Range, 3/8" Brass Fittings.	4,A3
9800-3070-LBT	Manifold, 5-Port, Low Range, 1/4" Brass Fittings.	4,A4
9800-3070-LBV	Manifold, 5-Port, Low Range, 3/8" Brass Fittings, Check Valves.	4,A3
9800-3070-LSS	Manifold, 5-Port, Low Range, 37° Flared Stainless Steel Fittings.	4,A3
9800-3070-LSV	Manifold, 5-Port, Low Range, 37° Flared Stainless Steel Fittings, Check Valves	4,A3
9800-3076-BS	Manifold, Flow Bank, 3/8" Brass Fittings.	2,A2
9800-3076-BT	Manifold, Flow Bank, 1/4" Brass Fittings.	2,A2
9800-3080-X-U	Panel, Two Pipes, Resistive Transducers, Low Range	Discontinued
9800-3080-X-1	Panel, Two Pipes, Flow Transducers, Low Range.	Discontinued
9800-3080-X-9	Panel, Two Pipes, No Transducers, Low Range	Discontinued
9800-3080-Y-U	Panel, Two Pipes, Resistive Transducers, Medium Range	Discontinued
9800-3080-Y-1	Panel, Two Pipes, Flow Transducers, Medium Range	Discontinued
9800-3080-Y-2	Panel, Two Pipes, Dual Transducers, Medium Range	Discontinued
9800-3080-Y-9	Panel, Two Pipes, No Transducers, Medium Range	Discontinued
9800-3080-Z-1	Panel, Two Pipes, Flow Transducers, High Range	Discontinued
9800-3080-Z-2	Panel, Two Pipes, Dual Transducers, High Range	Discontinued
9800-3080-Z-9	Panel, Two Pipes, No Transducers, High Range.	Discontinued
9800-3080-Z-U	Panel, Two Pipes, Resistive Transducers, High Range.	Discontinued
9800-3081-19	Panel, Instrument, 19" Width.	Discontinued
9800-3081-23	Panel, Instrument, 23" Width	6,B1
9800-3081-PAF	Panel, Instrument, Positive Air Flow	Discontinued
9800-3082-HBS-1	Panel, Distribution, High Range, 3/8" Brass Fittings, Flow Transducer	Discontinued
9800-3082-HBS-2	Panel, Distribution, High Range, 3/8" Brass Fittings, Dual Transducer.	Discontinued
9800-3082-LBS-1	Panel, Distribution, Low Range, 3/8" Brass Fittings, Flow Transducer	Discontinued
9800-3082-LBS-2	Panel, Distribution, Low Range, 3/8" Brass Fittings, Dual Transducer	Discontinued
9800-3082-MBS-1	Panel, Distribution, Medium Range, 3/8" Brass Fittings, Flow Transducer	Discontinued
9800-3082-MBS-2	Panel, Distribution, Medium Range, 3/8" Brass Fittings, Dual Transducer	Discontinued
9800-3082-MBS-9	Panel, Distribution, Medium Range, 3/8" Brass Fittings, No Transducer	Discontinued
9800-3082-MBS-U	Panel, Distribution, Medium Range, 3/8" Brass Fittings, Resistive Flow Transducer	Discontinued
9800-3083-X-1	Panel, One Pipe, Flow Transducer, Low Range	Discontinued
9800-3083-X-2	Panel, One Pipe, Dual Transducer, Low Range.	Discontinued
9800-3083-X-9	Panel, One Pipe, No Transducer, Low Range	Discontinued
9800-3083-X-U	Panel, One Pipe, Resistive Transducer, Low Range	Discontinued
9800-3083-Y-1	Panel, One Pipe, Flow Transducer, Medium Range	Discontinued
9800-3083-Y-2	Panel, One Pipe, Dual Transducer, Medium Range	Discontinued
9800-3083-Y-9	Panel, One Pipe, No Transducer, Medium Range.	Discontinued

9800-3083-Y-U	Panel, One Pipe, Resistive Transducer, Medium Range	Discontinued
9800-3083-Z-1	Panel, One Pipe, Flow Transducer, High Range	Discontinued
9800-3083-Z-2	Panel, One Pipe, Dual Transducer, High Range	Discontinued
9800-3083-Z-9	Panel, One Pipe, No Transducer, High Range	Discontinued
9800-3083-Z-U	Panel, One Pipe, Resistive Transducer, High Range	Discontinued
9800-3084-2	Panel, 1/2" Pipe Return, Two Pipes	Discontinued
9800-3085	Panel, Power Pipe Return, One Pipe	Discontinued
9800-3086	Panel, Delivery Pressure	Discontinued
9800-3088-23	Panel, Transducer, 5 Transducers, 23" Width	6,B1
9800-3089-23	Panel, Transducer, 10 Transducers, 23" Width	6,B1
9800-3090	Panel, Equipment Rack, 23" x 84"	6,B2
9800-3096	Panel, Power Supply	6,A3,6,B1/10,C6
9800-3097	Flow Finder, 0-475, Bracket, No Pipe Fittings	3,A2/7,A1
9800-3098	Flow Finder, 0-950 SCFH, Bracket, No Pipe Fittings	3,A2
9800-3099	Panel, Power Pipe	6,B1/7,A1
9800-3100	Tool, Flow Gauge	3,A3/4,A4/9,A1
9800-3105	Tool, Flow Direction Gauge	2,A2/9,A1
9800-3115	Tool, Portable Flow Rater	9,A1
9800-3120	Tool, Digital Pressure Gauge	9,A1
9800-3140	Tool, Humidity/Temperature Meter	9,A2
9800-3186	Panel, Digital, Miscellaneous, Power Supply, -24 VDC	6,A2
9800-3190	Flow Finder, 0-190 SCFH, Bracket, No Pipe Fittings	3,A2
9800-3196	Panel, Digital, Miscellaneous, DC to DC Converter	6,A3
9800-3197	Panel, Digital, Miscellaneous, Digital Direct Connect Module	6,A3
9800-3210	Tool, Direction of Flow Indicator	9,A2
9800-3266	Tool, Quick-Connect Flow Finder Attachment	9,A1
9800-3275	Tool, Half Inch Air Pipe Reamer	9,A3
9800-3282-HBS-1	Panel, Legacy Distribution, High Range, 3/8" Brass Fittings, Flow Transducer	Discontinued
9800-3282-HBS-2	Panel, Legacy Distribution, High Range, 3/8" Brass Fittings, Dual Transducer	Discontinued
9800-3282-HBS-U	Panel, Legacy Distribution, High Range, 3/8" Brass Fittings, Resistive Flow Transducer	Discontinued
9800-3282-LBS-1	Panel, Legacy Distribution, Low Range, 3/8" Brass Fittings, Flow Transducer	Discontinued
9800-3282-LBS-2	Panel, Legacy Distribution, Low Range, 3/8" Brass Fittings, Dual Transducer	Discontinued
9800-3282-LBS-U	Panel, Legacy Distribution, Low Range, 3/8" Brass Fittings, Resistive Flow Transducer	Discontinued
9800-3282-MBS-1	Panel, Legacy Distribution, Medium Range, 3/8" Brass Fittings, Flow Transducer	Discontinued
9800-3282-MBS-2	Panel, Legacy Distribution, Medium Range, 3/8" Brass Fittings, Dual Transducer	Discontinued
9800-3282-MBS-U	Panel, Legacy Distribution, Medium Range, 3/8" Brass Fittings, Resistive Flow TD	Discontinued
9800-3300-BS-0	Manifold, Flow Bank, Assembly, Single, SSI PTD, 3/8" Brass Fittings	2,B1
9800-3300-BS-9	Manifold, Flow Bank, Assembly, Single, No TD, 3/8" Brass Fittings	2,B1
9800-3300-BS-U	Manifold, Flow Bank, Assembly, Single, UE Resistive Pressure Transducer, 3/8" Brass Fittings	2,B1
9800-3300-BT-0	Manifold, Flow Bank, Assembly, Single, SSI PTD, 1/4" Brass Fittings	2,B2
9800-3300-BT-9	Manifold, Flow Bank, Assembly, Single, No PTD, 1/4" Brass Fittings	2,B2
9800-3301-BS-0	Manifold, Flow Bank, Assembly, Dual, SSI PTD, 3/8" Brass Fittings	2,B2
9800-3301-BS-9	Manifold, Flow Bank, Assembly, Dual, No PTD, 3/8" Brass Fittings	2,B2
9800-3301-BS-U	Manifold, Flow Bank, Assembly, Dual, UE Resistive Pressure Transducer, 3/8" Brass Fittings	2,B2
9800-3301-BT-0	Manifold, Flow Bank, Assembly, Dual, SSI PTD, 1/4" Brass Fittings	2,B2
9800-3301-BT-9	Manifold, Flow Bank, Assembly, Dual, No PTD, 1/4" Brass Fittings	2,B2
9800-3401	Panel, Blank, 3.5" x 23"	6,B1
9800-3402	Panel, Blank, 7" x 23"	6,B1
9800-3403	Panel, Blank, Reinforced, 3.5" x 23"	6,B1
9800-3496	Panel, Equipment Rack, Gated Wall Mount	6,B2
9800-3504	Tool, Power Pipe Reamer	7,A9/9,A3
9800-3505	Tool, Air Pipe Cutter, Power Pipe	3,A3/7,A9/9,A2
9800-3507	Tool, Power Pipe, Plug Gauge	7,A10
9800-3508	Tool, Air Pipe Cutter, 1/2" Pipe	3,A3/7,A9/9,A2
9800-3509	Tool, Replacement Blades, Pipe & Tubing Cutter	3,A3/7,A9/9,A3
9800-3510	Tool, Standard Jaw Pinchers	3,A3/9,A3
9800-3515	Pipe/Power Pipe, Cable ID Tags	3,A3/7,A9
9800-3516	Tool, Torque Wrench, 3/8" Square Drive	9,A3

9800-3600	Tool, Transducer Test Meter	9,A2
9800-3682-HBS-2	Panel, Digital, Legacy Distribution, High Range, 3/8" Brass Fittings, Dual Transducer	6,A2
9800-3682-LBS-2	Panel, Digital, Legacy Distribution, Low Range, 3/8" Brass Fittings, Dual Transducer	6,A2
9800-3682-MBS-2	Panel, Digital, Legacy Distribution, Medium Range, 3/8" Brass Fittings, Dual Transducer.	6,A2
9800-3750	Tool, Ultrasonic Leak Detector	9,A2
9800-3755	Tool, Hydrogen Leak Detector	9,A2
9800-3780-Y2	Panel, Digital, Two Pipes, Medium Range, Dual Transducer	6,A1
9800-3780-Z2	Panel, Digital, Two Pipes, High Range, Dual Transducer.	6,A1
9800-3782-HBS-2	Panel, Digital, Distribution, High Range, 3/8" Brass Fittings, Dual Transducer	6,A1
9800-3782-LBS-2	Panel, Digital, Distribution, Low Range, 3/8" Brass Fittings, Dual Transducer	6,A1
9800-3782-MBS-2	Panel, Digital, Distribution, Medium Range, 3/8" Brass Fittings, Dual Transducer.	6,A1
9800-3783-Y2	Panel, Digital, One Pipe, Medium Range, Dual Transducer	6,A1
9800-3783-Z2	Panel, Digital, One Pipe, High Range, Dual Transducer.	6,A1
9800-3799-L2	Panel, Digital, Power Pipe, Low Range, Dual Transducer.	6,A2
9800-3799-M2	Panel, Digital, Power Pipe, Medium Range, Dual Transducer	6,A2
9800-3901-CSV-2	Manifold Assembly, PAF Source, Single, Custom Range, Stainless Steel Fittings, Check Valves, Dual Transducer	4,B7
9800-3901-LBS-2	Manifold Assembly, PAF Source, Single, Low Range, 3/8" Brass Fittings, Dual Transducer	4,B7
9800-3901-LBV-2	Manifold Assembly, PAF Source, Single, Low Range, 3/8" Brass Fittings, Check Valves, Dual TD. . .	4,B7
9800-3902-CBV-2	Manifold Assembly, PAF Return, Single, Custom Range, 3/8" Brass Fittings, Check Valves, Dual Transducer.	4,B8
9800-3902-MSV-2	Manifold Assembly, PAF Return, Single, Medium Range, 37° Stainless Steel Fittings, Brass Check Valves, Dual Transducer	4,B8
9800-3903-HSV-2	Manifold Assembly, PAF Source, Dual, High Range, Stainless Steel Fittings, Check Valves, Dual Transducer.	4,B7
9800-3903-MBS-2	Manifold Assembly, PAF Source, Dual, Medium Range, 3/8" Brass Fittings, Dual Transducer	4,B7
9800-3903-MBV-2	Manifold Assembly, PAF Source, Dual, Medium Range, 3/8" Brass Fittings, Check Valves, Dual Transducer.	4,B7
9800-3904-CBS-2	Manifold Assembly, PAF Return, Dual, Custom Range, 3/8" Brass Fittings, Dual Transducer.	4,B8
9800-3904-CBV-2	Manifold Assembly, PAF Return, Dual, Custom Range, 3/8" Brass Fittings, Check Valves, Dual Transducer.	4,B8
9800-3904-CSV-2	Manifold Assembly, PAF Return, Dual, Custom Range, 37° Flared Stainless Steel Fittings, Check Valves, Dual Transducer	4,B8
9800-3905-BS-0	Sensor, Assembly, Pressure Relief (5-Port).	4,B8
9800-3906-BS-0	Manifold, Assembly, Pressure Relief	4,B8
9800-3915-BS-0	Manifold, Assembly, Pressure Relief (10-Port)	4,B8
9800-4000-BB	Sensor, Pressure TD, Stand-alone, Barbed Fitting	8,A1
9800-4000-BS	Sensor, Pressure TD, Stand-alone, 3/8" Tubing Fitting	8,A1
9800-4000-SC	Sensor, Pressure TD, Assembly Replacement, 1/8" Tubing Fitting	8,A3
9800-4001-BB	Sensor, Pressure TD, Panel Mount, Barbed Fitting.	8,A1
9800-4001-BR	Sensor, Pressure TD, Panel Mount, 90° Barbed Fitting	8,A2
9800-4001-BS	Sensor, Pressure TD, Panel Mount, 3/8" Tubing Fitting.	8,A2
9800-4002-BB	Sensor, Pressure TD, Housing Mount, Barbed Fitting	8,A2
9800-4002-BS	Sensor, Pressure TD, Housing Mount, 3/8" Tubing Fitting	8,A2
9800-4002-BT	Sensor, Pressure TD, Housing Mount, 1/4" Tubing Fitting	8,A2
9800-4003-SS	Sensor, Pressure TD, Stand-alone, 37° Flared Tubing Fitting	8,A2
9800-4004-BT	Sensor, Pressure TD, Stand-alone, 1/4" Tubing Fitting	8,A2
9800-4004-SC	Sensor, Pressure TD, Assembly Replacement, 1/8" Tubing Fitting	8,A3
9800-4010-W	Sensor, Flow TD, Resistive, 0-9.5 SCFH	8,A3
9800-4010-X	Sensor, Flow TD, Resistive, 0-19 SCFH.	8,B3
9800-4010-Y	Sensor, Flow TD, Resistive, 0-47.5 SCFH	8,B3
9800-4010-Z	Sensor, Flow TD, Resistive, 0-95 SCFH.	8,B3
9800-4012	Sensor, Pressure TD, Stand-alone, Resistive, 0-9.5 PSI	8,A3
9800-4013	Sensor, Pressure TD, Housing Mount, Resistive, 0-9.5 PSI	8,A3
9800-4050	Sensor, Barometric TD, Stand-alone	8,D1
9800-4100-BB	Sensor, Flow TD, Stand-alone, Barbed Fittings.	8,B1
9800-4100-BR	Sensor, Flow TD, Stand-alone, 90° Barbed Fittings	8,B1
9800-4100-SC	Sensor, Flow TD, Assembly Replacement, 3/8" Wire Cover Tubing Fittings	8,B2

9800-4101-BB	Sensor, Flow TD, Panel Mount, Barbed Fitting	8,B1
9800-4101-BR	Sensor, Flow TD, Panel Mount, 90° Barbed Fitting	8,B2
9800-4102-BB	Sensor, Flow TD, Housing Mount, Barbed Fitting	8,B2
9800-4103-BB	Sensor, Flow TD, Stand-alone, Barbed Fitting	8,B2
9800-4103-BR	Sensor, Flow TD, Stand-alone, 90° Barbed Fitting	8,B2
9800-4103-SC	Sensor, Flow TD, Assembly Replacement, 37° Flared Tubing Fittings	8,B3
9800-4104-BB	Sensor, Flow TD, Stand-alone, Barbed Fitting	8,B2
9800-4104-BR	Sensor, Flow TD, Stand-alone, 90° Barbed Fitting	8,B2
9800-4104-SC	Sensor, Flow TD, Assembly Replacement, 1/4" Wire Cover Tubing Fittings	8,B3
9800-4200-BB	Sensor, Dual TD, Stand-alone, Barbed Fittings	8,C1
9800-4200-BR	Sensor, Dual TD, Stand-alone, 90° Barbed Fittings	8,C1
9800-4200-SC	Sensor, Dual TD, Assembly Replacement, 3/8" Wire Cover Tubing Fittings	8,C3
9800-4201-BB	Sensor, Dual TD, Panel Mount, Barbed Fitting	8,C2
9800-4201-BR	Sensor, Dual TD, Panel Mount, 90° Barbed Fitting	8,C2
9800-4202-BB	Sensor, Dual TD, Housing Mount, Barbed Fitting	8,C2
9800-4203-BB	Sensor, Dual TD, Stand-alone, Barbed Fitting	8,C2
9800-4203-BR	Sensor, Dual TD, Stand-alone, 90° Barbed Fitting	8,C2
9800-4203-SC	Sensor, Dual TD, Assembly Replacement, 37° Flared Tubing Fittings	8,C3
9800-4203-SCP	Sensor, Dual TD, Assembly Replacement, Pair Saver, 37° Flared Tubing Connector	8,C3
9800-4204-BB	Sensor, Dual TD, Stand-alone, Barbed Fitting	8,C2
9800-4204-BR	Sensor, Dual TD, Stand-alone, 90° Barbed Fitting	8,C3
9800-4204-SC	Sensor, Dual TD, Assembly Replacement, 1/4" Wire Cover Tubing Fittings	8,C3
9800-420N-SC	Sensor, Dual TD, Assembly Replacement, No Wire Cover	8,C3
9800-4305	Sensor, Transducer Housing, 5-Bank	8,E2
9800-4310	Sensor, Transducer Housing, 10-Bank	8,E2
9800-4400	Sensor, Water Level/Moisture Sensor	8,D2
9800-4410	Sensor, Relative Humidity/Temperature	8,D1
9800-4420MA3	Sensor, Cable Section Locator	5,A3/8,D1
9800-4430	Sensor, Nitrogen Tank	8,D1
9800-4450	Sensor, Contact Alarm Expander	8,D1
9800-4451	Panel, Digital, Miscellaneous, Contact Alarm Expander	6,A3
9800-4505	Sensor, AC Voltage Sensor	8,D1
9800-4848BBU	LSS, uM260, Backup Battery Kit	10,A3
9800-4849	LSS, Remote Dryer Monitoring Kit	10,A4
9800-4945	Computer, Cable, PMAP Engine to Digi PSII	5,B2
9800-4950	Computer, Cable, Digi PSII to Null Modem	5,B2
9800-4966	Computer, Cable, Standard Modem	5,A3
9800-4975	Computer, Cable, Corollary to Telton DTMF Modem	5,B3
9800-5021	Computer, Cable, Modem to Serial Printer	5,B2
9800-5022	Computer, Cable, Digi PSII to Modem	5,B2
9800-5023	Computer, Cable, Digi PSII to Multi-Tech Modem	5,A3
9800-5029	Computer, Cable, Digi PSII to Hayes MR 200 Modem	5,B2
9800-5032	Computer, Cable, Digi PSII to Telton DTMF Modem	5,A4
9800-5033	Computer, Cable, Digi to NMA	5,A4
9800-5055	Computer, Cable, 7-Foot RJ-45 Serial, Flat	5,A4
9800-5149	Computer, Miscellaneous, DigiPORTS/Xem 2U 19" Rack Chassis	5,A4
9800-5155	Computer, Miscellaneous, Digi AccelePort PORTS/16em Module™	5,A3
9800-5162	Computer, Miscellaneous, Digi AccelePort Power Supply	5,A4
9800-5167	Computer, Miscellaneous, Multi-Tech ZDXModemRack	5,A4
9800-5174	Computer, Modem, MultiModem ZDX 56Kbps Stand-alone	5,A3
9800-5175	Computer, Modem, MultiModem v.92 Voice / DTMF	5,A3
9800-5417	Computer, Miscellaneous, Digi PortServer II™	5,A3
9800-5422	Panel, Miscellaneous, Mini CO Manifold with regulator	6,B3/11,A2
9800-5429	Panel, Miscellaneous, Mini CO Manifold	6,B3/11,A2
9800-5432	Panel, Miscellaneous, Balance Manifold	6,B3
9800-5475	Computer, Cable, Hydra Cable, 24 Legs	5,B2
9800-5516	LSS, Remote Power Control, RPC-1 MD01	10,C6

9800-6002	LSS, Cable, 9-Pin, Male/Female Serial (DB-9)	10,B2
9800-6016-X	LSS, Cable, 25 Pair, Male/Female Connectors, Customer-Specific Length	10,B1
9800-6016-5	LSS, Cable, 25 Pair, Male/Female Connectors, 5 Feet	10,B1
9800-6016-10	LSS, Cable, 25 Pair, Male/Female Connectors, 10 Feet	10,B1
9800-6016-25	LSS, Cable, 25 Pair, Male/Female Connectors, 25 Feet	10,B1
9800-6016-100	LSS, Cable, 25 Pair, Male/Female Connectors, 100 Feet	10,B1
9800-6017-X	LSS, Cable, 25 Pair, Male/Male Connectors, Customer-Specific Length	10,B1
9800-6017-2	LSS, Cable, 25 Pair, Male/Male Connectors, 2 Feet	10,B1
9800-6017-5	LSS, Cable, 25 Pair, Male/Male Connectors, 5 Feet	10,B1
9800-6017-10	LSS, Cable, 25 Pair, Male/Male Connectors, 10 Feet	10,B1
9800-6017-25	LSS, Cable, 25 Pair, Male/Male Connectors, 25 Feet	10,B1
9800-6017-100	LSS, Cable, 25 Pair, Male/Male Connectors, 100 Feet	10,B1
9800-6018	LSS, Cable, Gender Bender, Back-to-Back Male, Threaded	10,B2
9800-6019	LSS, Cable, Gender Bender, Back-to-Back Female, Threaded	10,B2
9800-6020	LSS, Cable, Male/Female, Sparton (A)	10,B1
9800-6034-X	LSS, Cable, 25 Pair, Single Male/Raw End	10,B1
9800-6046	LSS, Sparton Subscriber Line Adapter Module (SSLAM)	10,C2
9800-6055	LSS, Connector Block, Wire Wrap, Dedicated	10,C2
9800-6055-C	LSS, Connector Block, Wire Wrap, Dedicated, M/F Connectors	10,C2
9800-6056	LSS, Connector Block, Wire Wrap, Subscriber	10,C2
9800-6058	LSS, Cable, 25 Pair, Male/Female, Sparton (B)	10,B1
9800-6059	LSS, Cable, 25 Pair, Male/Female, Sparton (C)	10,B2
9800-6060	LSS, Connector Block, Type 66 (Krone), Female Connectors	10,C3
9800-6061	LSS, Krone Block Cover	10,C5
9800-6062	LSS, Connector Block, Circuit Protector	10,C2
9800-6063	LSS, Connector Block, Type 66, No Connectors	10,C3
9800-6064	Tool, Impact for Type 66 Block	9,A3/10,C6
9800-6065	LSS, Connector Block Mounting Bar, Type 66	10,C4
9800-6066	LSS, Connector Block Standoff Bracket, Type 66	10,C4
9800-6067	LSS, Connector Block 5-Pin Protector Module	10,C2
9800-6068	LSS, Connector Block, Wire Wrap, Dedicated, 50-Pair	10,C2
9800-6071	LSS, Kit, Spare Parts	10,C4
9800-6073	LSS, Kit, Spare Fuses	10,C4
9800-6075	LSS, PC Board Case	10,C5
9800-6076-B	LSS, Connector Block, Type 66, Top Entry, Back Male Connectors	10,C3
9800-6076-L	LSS, Connector Block, Type 66, Top Entry, Left Male Connectors	10,C3
9800-6076-R	LSS, Connector Block, Type 66, Top Entry, Right Male Connectors	10,C3
9800-6076-S	LSS, Connector Block, Type 66, Top Entry, Side Male Connectors	10,C3
9800-6077-B	LSS, Connector Block, Type 66, Bottom Entry, Back Female Connectors	10,C4
9800-6077-L	LSS, Connector Block, Type 66, Bottom Entry, Left Female Connectors	10,C3
9800-6077-R	LSS, Connector Block, Type 66, Bottom Entry, Right Female Connectors	10,C3
9800-6077-S	LSS, Connector Block, Type 66, Bottom Entry, Side Female Connectors	10,C4
9800-6078	LSS, Connector Block, Type 66, Bottom/Top Entry, Side Male/Female Connectors	10,C4
9800-6079	Tool, Insertion, for Krone Block	9,A3/10,C6
9800-6080	LSS, Static Control Wrist Strap	10,C5
9800-6090	LSS, Connector Block Mounting Bar	10,C4
9800-6100	LSS, Subscriber Card	10,C1
9800-6110	LSS, Dedicated Relay Card	10,C1
9800-6116	LSS, Sparton Dedicated Replacement Card (SPDR)	10,C1
9800-6260L	LSS, uM260 Micro Monitor, LAN Version	10,A3
9800-6260M	LSS, uM260 Micro Monitor, Modem Version	10,A3
9800-6302	LSS, 289H Monitor	10,A1
9800-6302L	LSS, 289H Monitor, LAN Capability	10,A1
9800-6302T	LSS, 289H Monitor, Tone Capability	10,A1
9800-6302LT	LSS, 289H Monitor, LAN and Tone Capability	10,A1
9800-6302MD-36	LSS, 289H-M Monitor, SPDR, 36-Pair	10,A2
9800-6302MD-50	LSS, 289H-M, Dedicated, 50 Pair	10,A2
9800-6302MLD-36	LSS, 289H-M Monitor, SPDR, 36-Pair, LAN Capability	10,A2

9800-6302MLD-50	LSS, 289H-M Monitor, Dedicated, 50-Pair, LAN Capability.	10,A2
9800-6302MLS-25	LSS, 289H-M Monitor, Subscriber, 25-Pair, LAN Capability	10,A2
9800-6302MLTD-50	LSS, 289H-M Monitor, Dedicated, 50-Pair, LAN/Tone Capability.	10,A2
9800-6302MLTS-25	LSS, 289H-M Monitor, Subscriber, 25-Pair, LAN/Tone Capability	10,A2
9800-6302MS-25	LSS, 289H-M, Subscriber, 25 Pair	10,A2
9800-6302MTD-50	LSS, 289H-M Monitor, Dedicated, 50-Pair, Tone Capability	10,A2
9800-6302MTS-25	LSS, 289H-M Monitor, Subscriber, 25-Pair, Tone Capability	10,A2
9800-7560	Computer, Software, BackupEDGE	5,A2
9800-7570	Computer, Software, System Status Viewer	5,A2
9800-7590	Computer, Software, Office Extender	5,A2
9800-7591	Computer, Software, Office Extender (for uM260 Micro Monitors)	5,A2
9800-7592	Computer, Software, Office Extender (for CopperWATCH uM260 Micro Monitors).	5,A2
9800-7629	Computer, Software, PressureMAP, Version 29	5,A2
9800-7801	Computer, Software, CopperWATCH Version 1	5,A2
9801-2100	Pipe/Power Pipe, Installation Assembly Kit, Straight Splice	7,A5
9801-2200	Pipe/Power Pipe, Installation Assembly Kit, Straight Splice w/Valve	7,A5
9801-2201	Pipe/Power Pipe, Installation Assembly Kit, 1" Pipe to One 3/8" Tubing	7,A6
9801-2201E	Pipe/Power Pipe, Installation Assembly Kit, 1" Pipe End Point to One 3/8" Tubing	7,A6
9801-2202	Pipe/Power Pipe, Installation Assembly Kit, 1" Pipe to One CA3131 1/2" Pipe	7,A7
9801-3061	Manifold, Installation Assembly Kit, 3061 Assemblies	7,A7
9801-3062	Manifold, Installation Assembly Kit, 3062 Assemblies	7,A7
9802-3062-MBS-U	Manifold Assembly, Dual, Curved, Medium Range, 3/8" Brass Fittings, Resistive Flow Transducer.	4,B5
9802-3062-MBV-2	Manifold Assembly, Dual, Curved, Medium Range, 3/8" Brass Fittings, Check Valves, Dual Transducer.	4,B5
9900-0008	Tool, Flow Gauge Sampler, Replacement Kit	9,A3
9900-0018	Panel, Miscellaneous, 9-Port Manifold Kit	6,B2
9900-0260	LSS, uM260, Rack Mount Panel Kit	10,A4
9900-0500	Fitting, Teflon Ferrule (Qty. 10)	1,A2/7,A8
9900-1500	Miscellaneous Products, Purge Valve Service Kit.	11,A2
9900-6260	Computer, CopperWATCH Theft Termination Kit	Discontinued